



Tixolam AM 01

Chemical description

Product based on polysaccharides.

Main use

Rheology modifier and binder for ceramic glazes.

Typical values

Appearance: Homogeneous powder

pH (2% solution): 9 - 12

Viscosity (2% solution, Brookfield RVT @ 20 °C, 20 rpm): 2000 - 3500 cP

Product properties

TIXOLAM AM 01 has been developed to meet white-ware glazing requirements:

- short grinding time;
- short unloading from the mill and sieving time;
- no settling to avoid glazes sedimentation in tanks and reservoirs;
- long shelf life of glaze-slips;
- high flow capacity of spray guns;
- rheological behaviour suitable for the application on vertical or sloping surfaces, avoiding dropping and straining problems;
- very short drying time, compatible with high speed "robot" glazing systems;
- good texture and even surface;
- homogeneous coating of surfaces;
- good binding action avoiding crawling, excessive release of dust, cracks and other defects

TIXOLAM AM 01 has been designed to obtain very smooth and even surfaces after spraying, which allows to reduce the firing cycle maintaining a proper final appearance of the fired glaze.

To get this features TIXOLAM AM 01 features:

- Low viscosity
- Very short drying time
- Pseudoplastic rheology (with very low yield point)

By this way it is possible to obtain a very good texture, avoiding dropping and allowing to spray further layers of glaze almost immediately, which is an advantage to exploit in the best way the automated robot glazing systems.

ceramics.lamberti.com

TIXOLAM AM 01 can be used alone or together with other binders/rheology modifiers (i.e. Carbocel and other Tixolam) according to the required rheological parameters.

TIXOLAM AM 01 can be used also for traditional manual spraying, particularly on Fire Clay or Fine Fire Clay bodies that usually have a lower water absorption and need a shorter drying time.

Applications

TIXOLAM AM 01 is usually added into the glaze in quantity of 0.2 - 0.5 % (on solids).

The addition of TIXOLAM AM 01 can be done in different ways according to glaze feature, plant organisation and habits:

- Total or partial addition in powder form directly into the ball mill. To reduce grinding time, it is also possible to add TIXOLAM only in the last hour of grinding.
- Addition of TIXOLAM AM 01 into the glaze slip unloaded from the mill is very often done with a predispersed paste composed by 4 - 8 parts of Tixolam AM 01 and 96 - 92 parts of water, obtained through a high speed stirrer (standard mixing time: 5-10 minutes). This paste is then kept at rest for 12-24 hours before addition.
The addition to the glaze slip requires a "high speed" stirring, and a time between 20 minutes and 1 hour.
- Addition of TIXOLAM AM 01 in powder form directly into the glaze which has to be made carefully to get a complete and homogeneous dispersion of the binder without formation of clots.

Take also into consideration that glaze slips might show thinning or thickening behaviour in the first hours after addition of Tixolam.

Then we recommend a resting time to reach stable rheological parameters of the glaze before its use. The proper resting time depends on local working conditions and has to be checked on site.

TIXOLAM AM 01, due to its chemical composition, can be prone to bacterial attacks that can cause sudden



Lamberti
ceramics

changes of rheological characteristics of the glaze; then we recommend the use of antibacterial agents (i.e Carbosan from Lamberti) during glaze preparation to improve its consistency.

Storage and handling

TIXOLAM AM 01 is stable to prolonged storage under condition where extreme moisture does not occur. The shelf life is at least twelve months if this condition is observed.

Packaging

25 kg five-ply multiwall paper bag having two plies coated with polyethylene.

Material safety

Consult the Safety Data Sheet